



WWW.af-model.com billxiao@af-model.com











#### **Assembly**


### ① Install the head



## ② Install vertical tail



## ③ Install horizontal tail



#### **Box Contents**






① Cabin 4 Main wing 2 Head

3 Fuselage 6 Vertical tail

- ② Auxiliary tank Ventral fin
- ⑤ Horizontal tail
- Support rod


#### **Specifications**

-	ACE60-6kg	PNP
	Electronic retraction 3pcs	Installed
	12g*4pcs, Digital metal servos 25g*7pcs, Digital metal servos (twin bearing)	Installed
	Main Tank(1350cc)	Installed
•	Retractable all mental CNC machined rotating scale gear with E-brake wheels	Installed
i i i i i i i i i i i i i i i i i i i	Navigation Lamp System	Installed
((("I"))) ((("I")))	3S 2200-2500mAh/30C 2pcs (sold separately)	Redquired to Complete




#### **CG LOCATION**


Make sure the center of gravity(CG) is as indicated in the following diagram.



4 Install the main wing




⑤ Install cockpit




5


## ⑤ Install ventral fin



# ⑦ Install wingtip tank (



PA 3x50mm



PA 3x50mm

#### Accessories













